










Parts List

A x 1 	B x 4 	C x 1 		D x 4 	F x 4 
				E x 4 	G x 4 

Assembly Instructions



Attention:









1. Follow the assembly instructions shown above.
2. Do not use power tools to assemble.
3. Use the correct tool which is provided.
4. Do not tighten the screws until the items have been fully assembled.
5. Periodically check all fittings to ensure that none have come loose.
6. This item is designed for use by Children.
7. Do not place wooden furniture next to a heating source and or open fire.
8. Always supervise young children.
9. Do not use furniture if components are missing or broken.

For Information or Help with this product






Email help@star-kids-furniture.com

Write to Star Kids Furniture PO Box 340 Hunter Region MC NSW 2310

Parts List

A x 2 	B x 1 	C x 1 	D x 2 	E x 6 	G x 6 
				F x 4 	H x 1 

Assembly Instructions

Step 1 		Step 2 		
Step 3 		Step 4 		Step 5 

Attention:

1. Follow the assembly instructions shown above.
2. Do not use power tools to assemble.
3. Use the correct tool which is provided.
4. Do not tighten the screws until the items have been fully assembled.
5. Periodically check all fittings to ensure that none have come loose.
6. This item is designed for use by Children.
7. Do not place wooden furniture next to a heating source and or open fire.
8. Always supervise young children.
9. Do not use furniture if components are missing or broken.

For Information or Help with this product

Email help@star-kids-furniture.com

Write to Star Kids Furniture PO Box 340 Hunter Region MC NSW 2310